



**BUI0010000**

POS.	OMSCHRIJVING	ONDERDELEN
1	HANDGREEP COMPLEET	XSMV-00100
2	SCHAKELAAR	XSMV-00200
3	SCHROEF ST4X20	XSMV-00300
4	BUIS TBV HANDGREEP	XSMV-00400
5	BUIS TBV HANDGREEP	XSMV-00500
6	KABELKLEM	XSMV-00600
7	SCHROEF ST3,5X16	XSMV-00700
7A	CONDENSATOR	XSMV-007A0
8	TOERENREGELAAR	XSMV-00800
9	KABELTULE	XSMV-00900
9A	KABEL	XSMV-009A0
10	INBUS	XSMV-01000
11	SCHROEF M5X16	XSMV-01100
12	LAGERDEKSEL	XSMV-01200
12A	SPIE 4X14 (PASPEN)	XSMV-012A0
13	AS	XSMV-01300
14	STOFKAP	XSMV-01400
15	BORGRING	XSMV-01500
16	LAGER 6204DDU	XSMV-01600
16A	BORGRING	XSMV-016A0
18	SPIE TBV AS	XSMV-01800
19	TANDWIEL	XSMV-01900
19A	BORGRING	XSMV-019A0
20	LAGER 6000ZZ	XSMV-02000
22	TANDWIELBAK	XSMV-02100
22A	DICHTING	XSMV-022A0
23	MOER M8	XSMV-02300
24	LAGER	XSMV-02400
26	ANKER COMPLEET	XSMV-02600
27	LAGER 608ZZ	XSMV-02700
27A	KUNSTSTOF RING	XSMV-027A0
28	NAALDLAGER HK0810	XSMV-02800
29	TANDWIELAS	XSMV-02900
29A	SPIE	XSMV-029A0
30	TANDWIEL	XSMV-03000
30A	BORGRING	XSMV-030A0
31	LAGER 698ZZ	XSMV-03100
32	LAGER 608ZZ	XSMV-03200
33	PINION	XSMV-03300
34	SPIE	XSMV-03400
35	TANDWIEL	XSMV-03500
35A	VLAKE TUSSENRING Ø16x8x0.8	XSMV-035A0
37	NAALDLAGER HK0810	XSMV-03700
38	TANDWIEL	XSMV-03800
39	VERSNELLINGSPLAAT	XSMV-03900
40	DRAAIKNOP	XSMV-04000
41	KOGELTJE	XSMV-04100
42	VEER	XSMV-04200
43	HENDEL	XSMV-04300
44	SCHROEF ST3X16	XSMV-04400
45	LUCHTVERDELER	XSMV-04500
46	SCHROEF ST5X65	XSMV-04600
47	VEERRING	XSMV-04700
49	VELD	XSMV-04900
50	VELDHUIS	XSMV-05000
51	SCHROEF M5X25	XSMV-05100
52	KOOLBORSTELSET	XSMV-05200
53	KOOLBORSTELHOUDER	XSMV-05300
54	KOOLBORSTELKAP	XSMV-05400

55	KABELKLEM	XSMV-05500
56	SCHROEF ST3,0X16	XSMV-05600
57	ELEKTRO-UNIT	XSMV-05700
58	BESCHERMKAP	XSMV-05800
59	DEKSEL	XSMV-05900
60	SCHROEF 3,5X16	XSMV-06000
61	AANSLUITSNOER	XSMV-06100
62	KABELTULE	XSMV-06200